



1. PERFORMANCE


- 1) Measuring range : 0.05-0.6% 0.01-0.12%
- Number of pump strokes : 1 (100mL) 4 (400mL)
- (This detector tube is calibrated by Hexane.)
- 2) Sampling time : 1 minute / 1 pump stroke
- 3) Detectable limit : —
- 4) Shelf life : 3 years
- 5) Operating temperature : 10~40°C
- 6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
- 7) Reading : Direct reading from the scale calibrated by 1 pump stroke
- 8) Colour change : Orange → Dark green

2. RELATIVE STANDARD DEVIATION

RSD-low : 10% RSD-mid. : 10% RSD-high : 5%

3. CHEMICAL REACTION

Chromium oxide is reduced.



4. CALIBRATION OF THE TUBE

GAS CHROMATOGRAPHY

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	ppm	Coexistence
Benzene	Black stain is produced.	100	Higher readings are given.
Toluene	∕	200	∕
Xylene	∕	500	∕
Acetylene	Similar stain is produced.	—	∕
Ethylene	∕	—	∕
Cyclohexane	∕	—	∕
Aliphatic hydrocarbons (more than C ₃)	∕	—	∕
Alcohols		1.5%	The accuracy of readings is not affected.
Esters		1.5%	∕
Ketones		1.5%	∕

TEMPERATURE CORRECTION TABLE

Tube Readings (%)	Corrected Concentration (%)				
	10 °C (50 °F)	15 °C (59 °F)	20 °C (68 °F)	30 °C (86 °F)	40 °C (104 °F)
0.6	0.73	0.65	0.60	0.52	0.48
0.5	0.60	0.55	0.50	0.45	0.42
0.4	0.48	0.44	0.40	0.37	0.35
0.3	0.35	0.32	0.30	0.28	0.27
0.2	0.22	0.21	0.20	0.19	0.18
0.1	0.10	0.10	0.10	0.10	0.10
0.05	0.05	0.05	0.05	0.05	0.05