DIETHYL AMINE



1. PERFORMANCE

1) Measuring range 1-20 ppmNumber of pump strokes $1(100 \text{m} \ell)$

2) Sampling time : 1 minute/1 pump stroke

3) Detectable limit : 0.3 ppm4) Shelf life : 3 years5) Operating temperature $: 0 \sim 40 \,^{\circ}\text{C}$

6) Reading : Direct reading from the scale calibrated by 1 pump stroke

7) Colour change : Pale purple → Pale yellow

2. RELATIVE STANDARD DEVIATION

RSD-low: 10% RSD-mid.: 10% RSD-high: 10%

3. CHEMICAL REACTION

By reacting with Phosphoric acid, PH indicator is discoloured. $(CH_3CH_2)NH + H_3PO_4 \rightarrow [(C_2H_5)_2NH]_2HPO_4$

4. CALIBRATION OF THE TUBE

DIFFUSION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Ammonia	Similar stain is produced.	Higher readings are given.
Other Amines	"	"