
NITRIC ACID VAPOUR



1. PERFORMANCE

1) Measuring range 2-20 ppm 1-10 ppm Number of pump strokes $1(100\text{m}\ell)$ $2(200\text{m}\ell)$ 2) Sampling time 1.5 minutes/1 pump stroke

3) Detectable limit : 0.5ppm (200m $\ell)$

4) Shelf life : 1 year (Necessary to store in refrigerated conditions ; $0 \sim 10 \, ^{\circ}\text{C}$)

5) Operating temperature : $5 \sim 40 \,^{\circ}\text{C}$

6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE") 7) Reading : Direct reading from the scale calibrated by 1 pump stroke

8) Colour change : Pale yellow→Purple

2. RELATIVE STANDARD DEVIATION

RSD-low: 15% RSD-mid.: 15% RSD-high: 10%

3. CHEMICAL REACTION

PH indicator is discoloured.

4. CALIBRATION OF THE TUBE

ABSORPTIOMETRIC METHOD


5. INTERFERENCE AND CROSS SENSITIVITY

Substance		Interference	ppm	Coexistence
Hydrogen fluoride		Similar stain is produced.	8	The top of discoloured layer becomes unclear and higher readings are given.
Nitrogen dioxide	FIG.1	"	50	"
Hydrogen chloride	FIG.2	"		Higher readings are given.


(NOTE)

In case of 2 pump strokes, following formula is available for the actual concentration.

Actual concentration = $1/2 \times$ Temperature corrected value



Nitrogen dioxide (ppm) FIG.1 Influence of Nitrogen dioxide



CORRECTION FOR AMBIENT CONDITIONS:

