
DIBORANE



1. PERFORMANCE

1) Measuring range : 0.1-5 ppm 0.05-2.5 ppm 0.02-1.0 ppm Number of pump strokes $1 (100 \text{m} \ell) 2 (200 \text{m} \ell) 5 (500 \text{m} \ell)$

2) Sampling time 1 minute/1 pump stroke3) Detectable limit $0.01 \text{ ppm} (500\text{m}\ell)$ 4) Shelf life 2 years5) Operating temperature $0 \sim 40 \text{ °C}$

6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
7) Reading : Direct reading from the scale calibrated by 1 pump stroke

8) Colour change : Pale yellow→Reddish purple

2. RELATIVE STANDARD DEVIATION

RSD-low: 10% RSD-mid.: 10% RSD-high: 10%

3. CHEMICAL REACTION

By reacting with Mercuric cholride, Hydrogen chloride is liberated and PH indicator is discoloured. B2H6 + HgCl2→HCl

4. CALIBRATION OF THE TUBE

STANDARD GAS CYLINDER METHOD


5. INTERFERENCE AND CROSS SENSITIVITY


| Substance | | Interference | Coexistence | |
|-------------------|-------|--------------|----------------------------|--|
| Arsine | FIG.2 | | Higher readings are given. | |
| Phosphine | FIG.1 | | " | |
| Hydrogen selenide | | | " | |
| Monosilane | | | / (Boundery is unclear.) | |
| Disilane | | | " (") | |
| Monogermane | | | Not affected. | |

(NOTE)

In case of 2 and 5 pump strokes, the following formula is available for the actual concentration.

2 pump strokes : Actual concentration = Temperature corrected value \div 2 5 pump strokes : Actual concentration = Temperature corrected value \div 5





TEMPERATURE CORRECTION TABLE

| Tube | Corrected Concentration (ppm) | | | | | |
|-------------------|-------------------------------|------------------|------------------|------------------|-------------------|--|
| Readings (ppm) | 0 °C (32 °F) | 10 °C (50 °F) | 20 °C (68 °F) | 30 °C (86 °F) | 40 °C (104 °F) | |
| 5 | _ | 9 | 5 | 3.5 | 2.5 | |
| 4 | _ | 7 | 4 | 3 | 2 | |
| 3 | _ | 5 | 3 | 2.5 | 1.5 | |
| 2 | 8 | 3 | 2 | 1.5 | 1.3 | |
| 1 | 1.5 | 1 | 1 | 1 | 0.8 | |
| 0.5 | 0.5 | 0.5 | 0.5 | 0.5 | 0.5 | |
| 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | 0.1 | |