

1. PERFORMANCE


- 1) Measuring range : 1-20 ppm
Number of pump strokes : 1 (100ml)
- 2) Sampling time : 1 minute/1 pump stroke
- 3) Detectable limit : 0.3 ppm
- 4) Shelf life : 3 years
- 5) Operating temperature : 0 ~ 40 °C
- 6) Reading : The tube scale is calibrated based on Diethyl amine at 1 pump stroke and the tube has the same sensitivity for Trimethyl amine.
- 7) Colour change : Pale purple → Pale yellow

2. RELATIVE STANDARD DEVIATION

RSD-low : 10% RSD-mid. : 10% RSD-high : 10%

3. CHEMICAL REACTION

Phosphoric acid, PH indicator is discoloured.



4. CALIBRATION OF THE TUBE

DIFFUSION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Ammonia	Similar stains are produced	Higher readings are given.
Other amines	∕	∕