# METHYL BROMIDE



#### 1. PERFORMANCE

1) Measuring range : 10-500ppm Number of pump strokes : 1(100mL)

2) Sampling time : 2 minutes/1 pump stroke

3) Detectable limit : 1 ppm

4) Shelf life : 3 years (Necessary to store in refrigerated conditions;  $0 \sim 10^{\circ}$ C)

5) Operating temperature :  $0\sim40^{\circ}$ C

6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
7) Reading : Direct reading from the scale calibrated by 1 pump stroke

8) Colour change : White→Reddish orange

#### 2. RELATIVE STANDARD DEVIATION

RSD-low: 15% RSD-mid.: 10% RSD-high: 10%

## 3. CHEMICAL REACTION

By decomposing with an Oxidizer, Bromine is produced. Bromine reacts with o-Toluidine and red Orthoguinone is produced.

 $CH_3Br + I_2O_5 + CrO_3 + H_2SO_4 \cdot nSO_3 \rightarrow Br_2$ 

## 4. CALIBRATION OF THE TUBE

**GAS CHROMATOGRAPHY** 

## 5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	ppm	Coexistence
Halogen	Similar stain is produced.		Higher readings are given.
Halogenated hydrocarbon	//		//
Trichloroethylene	//	20	//
Tetrachloroethylene	//	40	//